

NE1 = MACHINE ON BUT NO POWER

NE2 = RINSE NOT HEATING

NE3 = NOT FILLING

NE4 = WASH NOT HEATING

NE5 = NOT WASHING

NE6 = NOT RINSING

NE7 = NOT DRAINING

# NORRIS CAFEMATE, CAFEMASTER, BT160 ADVANCED FAULT FINDING

